







GATEWAY SETUP	
<p>1. Create an account</p> <ol style="list-style-type: none"> Go to web.smartdivider.net/sign-up Complete the registration process 	
<p>2. Assemble the gateway</p> <ol style="list-style-type: none"> Screw the antenna into the gateway Connect the cable to the power block and gateway Plug it into an outlet within 30 feet of where you will be using the Smart Divider™ devices 	
<p>3. Reset the gateway</p> <ol style="list-style-type: none"> Press the button on the side of the gateway and hold it for at least 5 seconds <p>Note: If a red light appears, unplug the gateway, plug it back in, and try again</p>	
<p>4. Go to www.smartdivider.com website or download the Smart Divider™ mobile app (Android/Apple)</p>	
<p>5. Go to “Configure Gateway” screen</p> <ol style="list-style-type: none"> (Website) Select it from the top menu (App) Tap on the menu icon in the upper left corner and then tap on “Configure Gateway” 	

<p>6. Connect to the gateway</p> <ol style="list-style-type: none"> Go to your Wi-Fi settings on your PC/mobile phone/device (you will be prompted by the app to take you there) Connect to the gateway’s Wi-Fi network <ul style="list-style-type: none"> Select the network name that starts with “BLE-WIFI_” Enter password: 12345678 <p>Note: If you cannot find a network that starts with “BLE-WIFI_”, repeat step 4</p>	
<p>7. Complete gateway configuration</p> <ol style="list-style-type: none"> Return to the Smart Divider™ website or app Select or enter the local Wi-Fi network you want the gateway to access Enter the Wi-Fi password Tap on “CONFIGURE” 	

Congratulations! You have successfully configured your gateway!

If you have any issues during setup, please refer to our Troubleshooting Guide at www.smartdivider.net/support or contact us at 414-906-8995.